

Part Number: PT276-34071

Kit Contents

Item #	Quantity Req.	Description
1	1	Spare Tire Lock
2	1	Key
3	1	Order Form
4	1	Installation Instruction Sheet
5	1	Customer Notice Card
6	1	Envelope
7	1	ID Card

Hardware Bag Contents

Item #	Quantity Req.	Description
1		
2		
3		

Additional Items Required For Installation

Item #	Quantity Req.	Description
1		
2		
3		

Conflicts

--

Recommended Tools

Personal & Vehicle Protection	Notes
Special Tools	Notes
Installation Tools	Notes
Special Chemicals	Notes

General Applicability

All Tundra models

Recommended Sequence of Application

Item #	Accessory
1	
2	
3	

*Mandatory

Vehicle Service Parts (may be required for reassembly)

Item #	Part Number	Description
1	09150-0C010	Jack Handle
2	09114-0C030 09115-0C030	Extension Rods
3		

Legend

	STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.
	OPERATOR SAFETY: Use caution to avoid risk of injury.
	CAUTION: A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.
	TOOLS & EQUIPMENT: Used in Figures calls out the specific tools and equipment recommended for this process.
	REVISION MARK: This mark highlights a change in installation with respect to previous issue.
	SAFETY TORQUE: This mark indicates that torque is related to safety.

Procedure

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.



This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).


Please see your Toyota dealer for a copy of this document.


1. Assemble the Jack Handle and Lower the Spare Tire.

(a) Remove the tool bag from the storage location (Fig. 1-1a or Fig. 1b).



(b) Remove the jack handle (3) and extension rods (1 & 2) from the tool bag and assemble them (Fig. 1-2).







- (c) Insert the square end of the extension rod through the access hole in the bumper and into the lowering screw (Fig. 1-3).
- (d) Turn counterclockwise making sure the jack handle remains firmly fitted to the extension rods.
- (e) Lower the tire partially from the vehicle to a suitable height allowing access to the lowering screw.

+ CAUTION: Ensure the wheel is safely supported in that position to prevent the spare tire from swaying during the spare tire lock installation.


2. Install the Spare Tire Lock.



- (a) Install the spare tire lock assembly into the lowering screw (Fig. 2-1).
 - (1) Line up the cross pin on the spare tire lock with the slot on the lowering screw.
 - (2) Press the spare tire lock in place until it is fully seated into the bottom of the lowering screw.





- (b) Assemble the key assembly onto the hooked extension rod (Fig. 2-2).



- (c) Insert the extension rod with key through the access hole in the rear bumper (Fig. 2-3).
- (d) Rotate the key in the lock assembly until the lock and key patterns engage.
- (e) Turn the jack handle clockwise, making sure that the jack handle remains firmly fitted to the extension rod and raise the tire until it is stowed in its original position.

3. Complete the Installation.

- (a) Disassemble the jack handle, extension rod and key.
- (b) Place the jack handle, extension rod and key into the tool bag and return the bag to the vehicle storage area (Fig. 3-1a or Fig. 3-1b).
- (c) Place the ID card, order form, customer notice card and instruction sheet in the McGard envelope.
- (d) Place the envelope in the glove compartment.



Checklist - these points **MUST** be checked to ensure a quality installation.

<u>Check:</u>	<u>Look For:</u>
<p><u>Accessory Function Checks</u></p> <ul style="list-style-type: none"><input type="checkbox"/> Spare tire lock has been properly installed<input type="checkbox"/> Spare tire lock key storage<input type="checkbox"/> Customer documents<input type="checkbox"/>	<p>Verify spare tire lock is fully seated in the bottom of the lowering screw</p> <p>Key assembly is stowed with the jack handle and extensions and placed in the tool bag</p> <p>McGard envelope with documents is placed in the glove box</p>
<p><u>Vehicle Function Checks</u></p> <ul style="list-style-type: none"><input type="checkbox"/> Spare tire<input type="checkbox"/> Tool bag<input type="checkbox"/>	<p>Spare tire is stowed in its original position</p> <p>Tool Bag is stored and secured in the original position</p>
<p><u>Vehicle Appearance Check</u></p> <ul style="list-style-type: none"><input type="checkbox"/> After accessory installation and removal of protective cover(s), perform a visual inspection.	<p>Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMS Accessory Quality Shipping Standard.)</p>